

## PERIODIC MAINTENANCE SCHEDULE

The chart below lists the recommended intervals for all the required periodic service work necessary to keep the motorcycle operating at peak performance and economy. Mileages are expressed in terms of kilometers, miles and time for your convenience.

**NOTE:**

More frequent servicing may be required on motorcycles that are used under severe conditions.

### PERIODIC MAINTENANCE CHART

Item	Interval	km	1 000	6 000	12 000	18 000	24 000	
		miles	600	4 000	7 500	11 000	14 500	
		months	2	12	24	36	48	
Air cleaner element		—	I	I	R	I		
Exhaust pipe bolts and muffler bolts		T	—	T	—	T		
Exhaust control valve		I	—	I	—	I		
Valve clearance		—	—	—	—	I		
Spark plugs		—	I	R	I	R		
Fuel line		—	I	I	I	I		
Evaporative emission control system (E-33 only)		—	—	I	—	I		
Engine oil		R	R	R	R	R		
Engine oil filter		R	—	—	R	—		
Final gear oil		R	—	I	—	I		
Throttle cable play		I	I	I	I	I		
PAIR (air supply) system		—	—	I	—	I		
Throttle valve synchronization		I (E-33 only)	—	I	—	I		
Engine coolant		Replace every 2 years						
Radiator hose		—	I	I	I	I		
Clutch cable play		—	I	I	I	I		
Brakes		I	I	I	I	I		
Brake hoses		—	I	I	I	I		
		Replace every 4 years						
Brake fluid		—	I	I	I	I		
		Replace every 2 years						
Tires		—	I	I	I	I		
Steering		I	—	I	—	I		
Front fork		—	—	I	—	I		
Rear suspension		—	—	I	—	I		
Chassis bolts and nuts		T	T	T	T	T		

**NOTE:**

I = Inspect and clean, adjust, replace or lubricate as necessary

R = Replace

T = Tighten